



SV-1550

Wireless Phone Line Extender



Table of Contents

Safety precautions	2
Thank you	3
Unpacking	3
Base unit installation	4
Extension unit installation	5
Operating modes	7
Troubleshooting	8
Customer Service	9
Declaration of conformity	10

Safety Precautions

- Do not attempt to plug in your Wireless Phone Line Extender until you have read this owners manual.
- Read, understand and follow all instructions.
- The Wireless Phone Line Extender System does not operate during a power outage.
- The Wireless Phone Line Extender System can only be used for a single (analog) phone line.
- Choose an easily accessible socket-outlet close to the equipment you want to use.
- Equipment connected to the base and extension must be approved for telephone system.
- Unplug the system from the wall outlet before cleaning. Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning.
- Do not use this system near water; for example, near a bath tub, washbowl, kitchen sink or laundry tub, in a wet basement or near a swimming pool.
- Never spill liquid of any kind on the system.
- This system should never be placed near or over a heat radiator.
- This system should not be placed in a built-in installation unless proper ventilation is provided.
- Do not disassemble or open the system. Service must be done by a qualified service center of ONE FOR ALL.

Thank You

Thank you for purchasing the ONE FOR ALL "Wireless Phone Line Extender". ONE FOR ALL is continuously striving to develop, produce and market high quality innovative products. We hope the "Wireless Phone Line Extender" will give you the freedom of wireless control.

The Wireless Phone Line Extender is a wireless and cable free extension of the phone socket or VoIP adapter for an ordinary phone, modem, fax or satellite/cable set top box with integrated modem.


Please read the following thoroughly and observe the operating instructions and information provided. Keep this guide for future use.

Unpacking


Carefully remove units from packaging. If there is any visible damage DO NOT attempt to operate the Wireless Phone Line Extender. Contact your dealer or shipping carrier immediately.

BOX CONTENTS:

1. ONE BASE UNIT _____



2. ONE EXTENSION UNIT _____



3. ONE PHONE LINE CORD _____



4. WALL SOCKET ADAPTOR _____



5. BASE UNIT ADAPTOR _____




6. EXTENSION UNIT ADAPTOR _____



Base unit installation

1. Plug the wall socket adaptor in the existing phone wall socket.
2. Connect the enclosed phone line cord to the Base unit and connect the other end to the wall socket adaptor.
3. Connect your phone to the Base unit adaptor and connect Base unit adaptor to the Base unit.
4. Connect the Base unit to a power outlet and switch power on. The light on top of the Base unit should now glow green.


The Base unit is now installed.



Extension unit installation


The Extension unit can be connected to either a normal phone, modem, fax or satellite/cable set top box.

1. Connect the extension unit adaptor to the Extension unit.
2. Plug the phone line cord from your phone, modem, fax or satellite/cable set top box into the Extension unit.



- 3.** 3A: Connection of phone. Turn the switch to "S"-position for Speech (voice).
3B: Connection of modem, fax or satellite/cable set top box. Turn the switch to "C"-position for Computer (modem, fax or satellite/cable set top box).
- 4.** Plug the Extension unit into a power outlet and switch power on. The light on top of the Extension unit will after a short period glow green (if switch is on C) or yellow (if switch is on S).

The Extension unit is now installed and your Wireless Phone Line Extender are now ready for use.



Operating Modes

BASE UNIT		
Light shows	This means	Suggested fix
Steady Green	Base unit is ready No Extension units in use	None Normal operation
Flashing Green	The Wireless Telephone Line Extender is using telephone line	None Normal operation
No Light	No power to Base unit	Check that the Base unit is properly connected to a power outlet and the power is on

EXTENSION UNIT		
Light shows	This means	Suggested fix
Steady Green	Extension unit in computer/Data ("C") is registered and in range of Base unit and ready for use	None Normal operation
Steady Yellow	Extension in Speech/ voice ("S") is registered and in range of Base unit and ready for use	None Normal operation
Flashing Green	Extension unit in use (C mode)	None Normal operation
Flashing Yellow	Extension unit in use (S mode)	None Normal operation
No Light	No power to Extension unit	Check that the Extension unit is properly connected to a power outlet and the power is on

EXTENSION UNIT

Light shows	This means	Suggested fix
Steady Red	Extension unit is not registered to a Base unit	Contact our customer service department
Flashing Red to Yellow or Flashing Red to Green	Extension unit is registered but not locked to Base unit	Check that Base unit is powered up. If it is, Extension unit may be out of range of Base unit. Relocate either the Extension unit or the Base unit to bring the units closer together

Troubleshooting

Problem	Possible cause	Solution
No dialling tone available	<ul style="list-style-type: none">- Base unit power not on- Cables not correctly connected- Extension unit may not be registered to base- The Extension unit is out of reach	<ul style="list-style-type: none">- Check all power and cable connections. If in doubt please refer to the user manual. Check that the Extension unit switch is correctly set to either S or C- Relocate the Extension unit within signal reach of the Base unit (max 50m)
My modem/set top box/fax is not working	The Extension unit switch has not been set to modem functionality	Make sure that the Extension unit switch is set to C
Short "hissing" sound heard on phone attached to Extension unit when first picked up	The Extension unit switch has not been set properly	Make sure that the Extension unit switch is set to S

Problem	Possible cause	Solution
Phone connected to Extension unit rings one ring later than phone connected to Base unit	This is normal. One ring delay is necessary to allow transfer of Caller ID information from base to Extension unit	-

Warning:

- Do not use this equipment in places where volatile or explosive materials may be present.
- This equipment will be inoperable if mains power fails.
- For indoor use only.

Customer Service

If you still have questions about the operation of your Wireless Phone Line Extender and could not find the answer(s) in the trouble shooting section, you may want to contact the customer service department for assistance or visit our Internet-site: **www.oneforall.com**

Our internet-site has many advantages:

- 24 hours access
- no waiting time
- page for Frequently Asked Questions
- info about the ONE FOR ALL product range

Before contacting us, by Fax, E-mail or Phone, make sure to have the following information available;

1. The ONE FOR ALL **SV- 1550** Wireless Phone Line Extender.
2. The date of purchase (...../...../.....).
3. Clear description of the problem.

- ofahelp@uebv.com (Just send blank message, you will get auto-reply)
- fax: +31 53 432 9816
- tel: 0906 96 95 654 (£1 per minute)

Declaration of Conformity



We, Universal Electronics Inc., 6101 Gateway Drive, Cypress, CA 90630, U.S.A., and its subsidiaries

Universal Electronics BV, Institutenweg 21, 7521 PH Enschede,
ONE FOR ALL UK Ltd, Institutenweg 21, 7521 PH Enschede, Netherlands,

Declare under sole responsibility that the ONE FOR ALL Wireless Phone Line Extender (SV 1550)

is in conformity with the requirements of the EC directives:

99/5/EC Directive for radio facilities and telecommunication terminals.

The presumption of conformity with essential requirements regarding Council Directive 99/05/EC is ensured according to:

R&TTE: Directive 99/05/EC Standard: EN 301 406 V1.5.5 (2003-07)

Additionally, the Wireless Phone Line Extender is in conformity with the below mentioned directives:

EMC: Directive 89/336/EC Standard: EN 301 489-1 V1.4.1 (2002-08)
 EN 301 489-6 V1.2.1 (2002-08)

Safety: Directive 73/23/EC Standard: EN 60950-1 (2001 ed. 1)

Intended use:

The Wireless Phone Line Extender base unit is intended for being switched into the analog telephone network via the normal telephone plug. The Wireless Phone Line Extender extension unit is intended for being connected to the input of an analog phone or modem. Both units are supplied from the public mains supply. Any other use is deemed as not intended use. Unauthorized alterations or modifications, which are not described in the user manual, are not admissible.

Enschede, 10th of March 2006

A handwritten signature in black ink, appearing to read 'Paul Bennett', with a stylized flourish at the end.

Paul J. Bennett
As Managing Director of Universal Electronics BV



The crossed –out wheeled bin symbol that can be found on your product means that the product is covered by the European Directive 2002/96/EC and it indicates that this product should not be disposed of via the normal household waste stream.

To prevent possible harm to the environment or human health, please separate this product from other waste streams to ensure that it can be recycled in an environmentally sound manner.

For more details on available collection facilities, please contact your local govern office or the retailer where you purchased this product.

Guarantee

UNIVERSAL ELECTRONICS / ONE FOR ALL warrants to the original purchaser that this product will be free from defects in materials and workmanship under normal and correct use for a period of one (1) year from the date of original purchase. This product will be repaired or if necessary replaced free of charge if it has been proven to be defective within the one (1) year warranty period. The forwarding costs are on the account of the owner; the costs of returning the product are on the account of UNIVERSAL ELECTRONICS / ONE FOR ALL. This warranty does not cover damage or failures caused by products or services not supplied by UNIVERSAL ELECTRONICS / ONE FOR ALL, or which result from not mounting the product according to manual instructions. This also applies when the product has been modified / repaired by others than UNIVERSAL ELECTRONICS / ONE FOR ALL or if a fault is the result from accident, misuse, abuse, neglect, mishandling, misapplication, faulty installation, improper maintenance, alteration, modifications, fire, water, lightning, natural disasters, wrong use or carelessness. To obtain warranty service during the warranty period, please notice that we need your original purchase receipt so that we may establish your eligibility for service. If you have bought this product for purposes which are not related to your trade, business or profession, please remind that you may have legal rights under your national legislation governing the sale of consumer goods. This guarantee does not affect those rights.

Universal Electronics BV
Europe & International
P.O. Box 3332
7500 DH, Enschede
The Netherlands

SV-1550
703824



RDN 1310306